NOAA
R 333


AFT MAST (M)
FWD MAST (R)
JACKSTAFF (R)
A-FRAME (M) (RETRACTED)
A-FRAME (M) (DEPLOYED)
AFT DECK CRANE PORT/STBD (M)
AFT CONTROL STATION 02-60-1-C STBD (R)
PILOT HOUSE TOP
PILOT HOUSE 01-15-0-C
BRIDGE DECK
PASSAGE 02-20-0-L
BATH 02-1A -1-L
CO SR 02-14-1-L
UPPER DECK
PASSAGE 01-10-0-L
EMER GEN RM 01-6-0-E
FOYER 01-2-0-L
BOATSWAINS STRM 01-E-0-A
FOCSLE DECK
FIBERGLASS GRATING (M) 18" ABV MN DK
INSTRUMENT REPAIR SHP (M) 01-87-0-Q
COMPUTER LAB AND MISSION EVALUATIONS OFFICE 01-92-0-Q (M)
WCT LAB 01-52-1-Q (M)
ACOUSTIC MONITORING ROOM 01-87-0-Q (M)
BULWARK (M)
CRANE PEDESTAL PORT/STBD (M)
MOORING DNK STWG (M) 1-86-1-A
BOATSWAINS WORKSHOP AND BOAT GEAR LOCKER (M) 1-75-2-L
PASSAGE 1-52-0-L (M)
PASS 1-87-1-L
LIMEN LKR (M) 1-87-2-A
GEN WW SHOP 1-82-0-Q
DC LKR 1-61-0-A
OFFICERS MESS 1-52-0-L
PASS 1-9-0-L
CO LKR 1-87-0-A
PASS 1-8-0-L
GALLEY 1-62-0-Q
CREW MESS 1-34-0-E
MED TRTMT ROOM 1-29-0-E
PASSAGE 2-33-1-L
FREEZE ROOM 1-18-2-A
THAW ROOM 1-18-1-A
CHILL ROOM 1-14-1-A
PASSAGE 1-9-0-L
CHAIN LKR 1-6-1-0
STEWARDS STRM NO 2 1-E-0-A
MAIN DECK
DWL 14'-8"
AFT PEAK BLST TANK 2-44-2-W
STEERING GEAR ROOM 2-84-0-Q
VOID 2-32-2-V (M)
SW BALLAST TANK 1-66-2-W
SEAWATER SYSTEMS ROOM (M) 2-72-2-W
ANTI-ROLL TANK 2-72-0-W
FUEL OIL TANK 4-72-2-F (M)
PRPLN MOTOR ROOM (M) 3-60-0-E
GRATING 12'-0" ABL
MAIN CONTROL STATION 2-82-0-E
FALSE DK 9'-6" ABL
POTABLE WATER TK 3 1/2-52-2-W
VOID 2-52-0-V
GRATING 6'-0" ABL
MAIN GENERATOR ROOM 3-34-0-E
GRATING 8'-0" ABL
ENGR STRM NO 2 2-28-1-A
PASSAGE 2-23-1-L
LAUNDRY ROOM 2-23-3-0
EXERCISE ROOM 2-14-0-L
BOW THRUSTER ELEC MTR RM 2-8-0-Q
FORE PEAK BALLAST TK 4-8-0-W
LOWER PLATFORM 10'-0" ABL EXCEPT AS NOTED
HOLD
SEAWATER BLST (M)
SEAWATER BALLAST TANK (M) 4-60-0-W
SEAWATER BALLAST TANK (M) 4-57-0-W
ANTI-ROLL DUMP TANK (M) 4-40-0-W
VOID 4-34-0-V
SEAWATER BLST/BALLAST TK (M) 4-23-0-Q1-W
FUEL OIL TANK 4-14-1-F
DEPTH FINDER XDCR TRK (M) 4-32-1-F
SP SPEED LOG & XS XDCR TRK (M) 4- 4-23-1-T
FO TANK 4-6-2-F
BOW THRUSTER TUNNEL


UPTAKE SP P/S
3-34-0-E
DW
DW
PILOT HOUSE
03-15-0-C
WR. WC
03-25-1-L
TOP OF WINCH\SHIP
CONTROL STATION


STACK P/S
INMARSAT A (N)


DECK TIE DOWN FITTING
FIXED LIFERAIL (N)
REMOVABLE LIFELINES (N)
FIXED LIFERAIL (N)
JACOBS LADDER P/S (R)
OFFICER ON DUTY STATIONS NO. 2 (PORT) & 1 (STBD)
CHOCK PORT/STBD (N)
MF/HF XCVR 35' ANTENNA PLATFORM
SHORE POWER CABLE REELS (R)
FOROID STOWAGE 2-HIGH (TYP)
BRIDLE AND TOWER STOWAGE (TYP)
HATCH
20'-0" RIB (N)
MIRANDA DAVIT (N)
FIRE EXTINGUISHER (N)
REFUELING STATION (N)
2-HIGH REEL STWG (TYP)
10.000M CTD (N)
LIFERAIL (N)
PLATFORM (N)
GANGWAY STOWED (R)
LINE OF DECK OVER
BOLTED PLATE
GRATING (N)
J-FRAME CONTROLS AND CTD WINCH CONTROLS
OPERATOR STATION EXPOSED (N)
AFT CONTROL STATION (R)
03-66-1-C
LIDSHIP CRANE (N)
PLATFORM OVER (R)
25 PERSON INFLATABLE LIFERAFTS (R)
WINDOWS (N)
J-FRAME (N) (RETRACTED)
J-FRAME (N) (DEPLOYED)
FIXED LIFERAIL (N)
FIXED LIFERAIL (N)
REMOVABLE LIFERAIL (N)
DC LKR 02-40-0-A (M)
UPTAKE SPACE 3-34-0-E
CREW SR (1) 02-34-2-L
CREW SR (1) 02-28-2-L
CREW SR (1) 02-23-2-L
CHIEF MARINE ENGR SR 02-14-2-L
MOORING LINE LKR (N) P/S
JACKSTAFF (R)
PASSAGE 02-20-0-L
BATH 02-42-1-L
FAN ROOM 02-34-1-Q
CREW SR (1) 02-40-1-L
CREW SR (1) 02-27-3-L
SHIPS OFFICE 02-23-1-Q
COMMANDING OFFICER SR 02-14-1-L
STORES CRANE (R)
UPTAKE SPACE 3-34-0-E
DK GR LKR 02-34-3-A
DOOR (N)
38'-4" ABL NO SHEAR
38'-4" ABL AT FR 0 SHEAR

DECK TIE DOWN FITTING
HELIUM BOTTLE STWG (N) 01-72-2-A
TORDID STOWAGE 2-HIGH (TYP)
STAGING PLATFORM 36'-10" ABL
BUOY ASSEMBLY AREA (P&S)
PLATFORM OVER (N)
SHORE PWR CONNECTION BOX (N)
CLOVER LEAF FITTING (TYP)
17 FT INFLATABLE BOAT (R)
STOWAGE CRADLE (N)
BAXTER BOLT FITTING (TYP)
HATCHWAY (N)
GAS CAN STWG (R) (8 CANS TWO HIGH)
GAS STWG QUICK-RELEASE (N)
PASSAGE (N) 01-67-2-L
INSTR REPAIR ROOM (N) 01-67-0-Q
TRASH CMPCTR ROOM 01-67-1-Q (N)
HATCH (OV)
COMPUTER LAB AND (N)
MISSION OPERATIONS OFFICE 01-59-0-Q
ET SHOP 01-52-4-Q (N)
VEST (N) 01-55-2-L
AUTOSAL-INOMETER ROOM (N) 01-52-0-Q
WET LAB 01-52-1-Q (N)
J-FRAME (N) RETRACTED
CLOVER LEAF FITTING (TYP)
BAXTER BOLT FITTING (TYP)
J-FRAME (N) DEPLOYED
TIE DOWN FITTING AREA
PASSAGE (N) 01-52-2-L
PASSAGE 1-48-1-L
P/W HOSE BIBB
PASSAGE 01-48-1-L
GRATING (OV)
SECONDARY OPERATOR STATION J-FRAME CONTROL
OFFICER ON DUTY STATIONS NO. 4 (PORT) & 3 (STBD)
CLEAT PORT/STBD (N)
UPTAKE SPACE 3-34-0-E
CREW SR (2) 01-42-2-L
CREW SR (2) 01-34-2-L
CREW SR (2) 01-40-1-L
CREW SR (2) 01-34-1-L
UPTAKE SPACE 3-34-0-E
CREW SR (1) 01-29-2-L
CREW SR (1) 01-24-2-L
CREW SR (1) 01-20-2-L
CREW SR (1) 01-14-2-L
PASSAGE 01-10-0-L
CREW SR (2) 01-29-1-L
CREW SR (1) 01-20-1-L
CREW SR (1) 01-14-3-L
EMERGENCY GENERATOR ROOM 01-6-0-E
ENGR STRM NO 1 01-1-2-A
BOATSWAIN'S STRM 01-E-0-A
FOYER 01-2-0-L
STEWARDS STRM NO 1 01-2-1-A
28'-10" ABL
NO SHEAR
SHEAR
29'-10" ABL AT FR 0


NO SHEAR
20'-0" ABL
SHEAR
21'-0" ABL AT FR 0
CHOCK FDN PORT/STBD (N)
OFFICER ON DUTY STATION NO. 5
CLEAT PORT/STBD (N)
CAPSTAN FND P/S (N)
SCUTTLE (OV)
BERP (OV)
CRANE FND P/S (N)
BRAILING WINCH FND P/S (N)
COMPACTED TRASH STWG 1-86-2-A (N)
WEAT
VOID 1-86-01-V (N)
MATCH OVER TYP (P/S)
MOORING LINE STWG 1-86-1-A (N)
A FRAME FND P/S (N)
STEERING GEAR RM VENT P/S (N)
MOORING BITT FND P&S (N)
30"X30" WT HATCH P/S (N)
WT HATCH 4'-0" X 4'-0" (N)
PLATFORM (N)
LADDER P/S (N)
DOOR (N) PORT/STBD
OFFICER ON DUTY STATION NO. 6
FIBERGLASS GRATING (N)
18" ABOVE MAIN DECK
KNEE (N)
PASSAGE (N) 1-75-2-L
HATCHWAY (N) 54"X30"
STEP
BOATSWAINS WORKSHOP AND BOAT GEAR LOCKER 1-75-0-Q (M)
PAINT LKR 1-75-1-Q
18" COAMING NT TYP (N)
BUOY ASSEMBLY AREA (P/S) (OVER)
HATCHWAY OVER (N)
FORECASTLE DECK (OVER)
CREW SR (1) 1-67-2-L
CREW SR (1) 1-62-2-L
CREW SR (1) 1-57-2-L
CREW SR (1) 1-54-2-L
CREW SR (1) 1-47-2-L
CREW SR (1) 1-42-2-L
T/S 1-66-2-L
T/S 1-58-2-L
T/S 1-46-2-L
PASSAGE (M) 1-52-2-L
STEP
LIN LKR 1-67-2-A
PASSAGE 1-67-1-L
FAN ROOM 1-67-3-0
OC LKR 1-61-0-A
GENERAL WORKSHOP 1-62-0-Q
OFFICER MESS 1-52-0-L
GRATING
CC LKR 1-47-0-A
PASSAGE 1-45-1-L
GALLEY 1-42-0-Q
DOOR (M)
HALON BTL RM 1-37-2-Q
UPTAKE SPACE 3-34-0-E
FAN ROOM 1-34-2-Q
PASSAGE 1-9-0-L
CREW MESS 1-34-0-L
UPTAKE SPACE 3-34-0-E
PANTRY (M) 1-37-1-Q
CREW SR (2) 1-29-2-L
CREW SR (3) 1-23-2-L
T/S 1-27 2-L
PASSAGE 1-9-0-L
MED TRTMT ROOM 1-29-0-L
BATH 1-32-1-L
PASSAGE (M) 2-23-1-L
BATH 1-23-1-L
CREW SR (1) 1-23-3-L
RECREATION ROOM 1-14-2-L
THWT ROOM 1-17-1-A
FREEZE ROOM 41-18-1-A
CHILL ROOM 1-14-1-A
SHIP'S STORE 1-6-4-0
DRY PROVISIONS STRM 1-8-3-A
CHAIN LKR 1-6-2-0
CHAIN LKR 1-6-1-Q
STEWARDS STRM 1-6-0-A


AFT PEAK BALLAST TANK 3-94-2-W
SW BALLAST TANK 4-86-2-W
HATCHWAY OVER (M)
FUEL OIL TANK 4-72-4-F
LUBO TANK 2-60-2-F
FUEL OIL TANK (M) 4-80-2-F
FUEL OIL SERV TANK 4-52-4-F
VOID 4-34-01-V
SLIDING WT DOOR (M)
REMINGED DOOR (M)
SCUTTLE (N)
AIR COND MCHRY ROOM 2-23-2-O
FUEL OIL TANK 4-14-2-F
FUEL OIL TANK 4-6-2-F
FOREPEAK BALLAST 4-8-0-W
VOID 2-92-2-V (M)
STEERING GEAR ROOM 2-94-0-Q
DECK 12'-6" ABL
SCIENTIFIC STOREROOM 2-77-2-A (M)
HATCHWAY OVER (M)
ANTI-ROLL TANK 2-72-0-W
4'-6" ABL
9'-6" ABL
12'-0" ABL
PRPLN MOTOR ROOM (M) 3-60-0-E
MAIN CONTROL STATION 2-52-0-E
MAIN GENERATOR ROOM 3-34-0-E
BHD WT (M)
TUNNEL 3-72-1-L (13'-6" ABL)
STEP
DIVE LKR (N) 2-77-1-A
PASS 2-23-1-L
BERP (N)
EXERCISE ROOM 2-14-0-L
BOW THRUSTER ELECTRIC MOTOR RM 2-6-0-0
℄ SHIP
ENG'R STRM NO 2 2-28-1-A
LAUNDRY ROOM 2-23-3-O
SEWAGE MCHRY RM 2-28-3-O
FUEL OIL TANK 4-14-1-F
FUEL OIL TANK 4-6-1-F
AFT PEAK BALLAST TANK 3-94-1-W
SW BALLAST TANK 4-86-1-W
FUEL OIL TANK 4-80-1-F
FUEL OIL TANK 4-72-3-F
FUEL OIL TANK (M) 4-80-1-F
FUEL OIL SERV TANK 4-52-3-F
VOID 4-34-01-V
LUBO TANK 2-60-1-F
NEW DECK AS NOTED
FR


FUEL OIL TK
4-52-2-F
OILY WASTE TK
4-60-2-F
FUEL OIL SERV TK
4-52-4-F
LUBO SETTLING TK
3-54-2-F
VOID
4-34-01-V
FUEL OIL TK
4-72-4-F
SHAFT ALLEY
RECESS P&S
FUEL OIL TANK
4-72-2-F
PRPLN MOTOR ROOM
3-52-01-E
POTW TK
3-1/2-52-2-W
POTW TK
3-1/2-52-1-W
MAIN GENERATOR ROOM
3-34-0-E
SEAWATER BALLAST TANK
4-23-2-W
FUEL OIL TANK
4-14-2-F
THRUSTER ROOM (M)
4-6-0
FOREPEAK BALLAST TANK
4-8-0-W
SEAWATER BALLAST TK (M)
4-25-0-W
VOID
VOID
HATCHWAY (OVER)
PASSAGE (N)
3-72-1-L
FUEL OIL TANK
4-72-1-F
FUEL OIL TK
4-72-3-F
FUEL OIL TANK
4-14-2-F
SEAWATER BALLAST TANK
4-23-3-W
MULTIBEAM, SPEED LOG
XDCR TRK (M)
4-23-1-T
MULTIBEAM & DEPTH
FINDER XDCR TRK (M)
4-32-0-T
WASTE WATER TANK
4-23-1-W
FUEL OIL TK
4-52-1-F
OILY WASTE TK
4-60-1-F
FUEL OIL SERV TK
4-52-3-F
VOID
4-34-01-V
℄ SHIP